



NOTE: C.P.T. (CREOSOTE PRESSURE TREATED)

NOTE: CONSULT LOCAL HEALTH AND BUILDING CODE AUTHORITIES BEFORE STARTING CONSTRUCTION

NOTE: USE 1x6 BRACES NAILED UNDER PURLINS.

ALL LUMBER SHALL BE STRESS GRADED TO PROVIDE 1500 PSI FIBER STRESS IN BENDING, AND 1350 PSI IN COMPRESSION. ONE TRUSS CAN SAFELY CARRY A LOAD OF 200 LBS. PER FOOT OF SPAN. DIMENSIONS OF MEMBERS SHOWN OTHER THAN POSTS ARE BASED ON THE USE OF DRESSED LUMBER.

