



- NOTES:
1. P.T. = PRESSURE TREATED. TREAT TO A PRESERVATION RETENSION OF 5-7 POUNDS PER CUBIC FOOT AS PER A.W.P.A. STANDARDS.
  2. BALES WILL SETTLE AND SPREAD. ALLOW 4'-5" ON ALL SIDES OF EACH BALE WHEN PLANNING STORAGE.
  3. SELECT TRUSS THAT SUPPORTS SNOW AND WIND LOADS FOR YOUR AREA. TRUSSES 4' O.C. (2' O.C.) DESIGN SHOWN IS FOR 30 LBS. PER SQ. FT. REQUIREMENTS FOR A 30 LBS. PER SQ. FT. SNOW LOAD.

