



UIB-01 / UIB-02 Driver Software for MRS series

UIB-01 / 02 Driver Software for MRS series

The UIB-01 / 02 is a USB interface board designed for installation in the expansion slot of products belonging to the ZOOM MRS series (hereafter simply called "MRS series"). When the UIB-01 / 02 is installed in the MRS series, you can establish a USB connection between the unit and a computer (Windows/Macintosh), allowing you to backup and restore project data, and to convert audio track data of the MRS series into audio data for use on the computer.

OPERATING ENVIRONMENT

The UIB-01 / 02 have the following hardware and software requirements.

- Compatible MRS series models
MRS-1044 (CD), MRS-1266 (CD), MRS-802(CD), MRS-1608(CD)
- Computer
Windows PC (166 MHz Pentium or higher recommended) with USB connector or
Apple Macintosh series computer with USB connector
* NEC PC-9800 series is not supported.
- Free hard disk space
100 MB or more
- RAM
32 MB or more

[NOTE]

Even when the above requirements are met, correct operation on all types of computers is not assured.
Depending on individual specifications and system conditions, there may be cases where incompatibilities exist.

User Agreement

The specifications of this software and/or the contents of this document are subject to change without notice. Zoom will not bear any responsibility for damages incurred during use or as a result of using this software, or for any claims regarding this software or use thereof by a third party. Any unauthorized distribution, sales, lease, rental, altering or reverse engineering of this software is strictly forbidden.

Download

Please download the driver meeting your environment in accordance with the following table. The mark "●" doesn't need to download the driver supplied by ZOOM as it works with OS standard driver.

UIB-01

	MRS-1608 / 1266 / 802	MRS-1044
Windows 98/98SE	○	○
Windows Me	○	○
Windows 2000	○	○
Windows XP	○ (*1)	○ (*1)
Mac OS 9.1	○	x

Mac OS 9.2.1, 9.2.2	○	x
Mac OS X	x	x

UIB-02 (*2)

	MRS-1608 / 1266 / 802	MRS-1044
Windows 98/98SE	○ (*3)	○ (*3)
Windows Me	●	●
Windows 2000	●	●
Windows XP	● (*1)	● (*1)
Mac OS 9.1	●	x
Mac OS 9.2.1, 9.2.2	●	x
Mac OS X	● (*4)	x

(*1) When you install a driver in Windows XP, it displays confirmation screen for license authentication. However, as we confirmed operation check, please continue to install, in disregard for the screen.

(*2) UIB02 corresponds with USB standard Version 2.0 and allows you to transfer the data at a faster pace. However in case USB port of computer side doesn't meet USB2.0, it conforms to USB1.1.

(*3) On Windows 98 / 98SE, when you install driver with CD-ROM coming with UIB-02, it sometimes happens that installation is not complete. However, please download and use uploading driver which has resolved this problem.

(*4) On Mac OS 10.2.4, it sometimes happens the computer doesn't recognize MRS series. In that case, please download the driver which meets Mac OS 10.2.4.

UIB-01 Driver Software for Windows	exe File 96K	Download
UIB-01 Driver Software for Macintosh	sit File 44K	Download
UIB-02 Driver Software for Windows 98/98SE	exe File 88K	Download
UIB-02 Driver Software for Macintosh OS 10.2.4	hqx File 40K	Download

[Please download](#) operation manual for UIB-01/02 from "Manual" in "Download" page.